

Care & Maintenance

# Mahogany



Walters™



Cayo Collection

## Guidelines.

- Maintain a controlled environment indoors.
- Avoid high temperature change.
- Never use abrasive cleaners.
- Clean up spills immediately.
- Avoid excessive moisture.
- Polish your furniture periodically.

## Mahogany Care.

Walters' mahogany furniture is an excellent choice for fine indoor furniture applications. Mahogany has a straight, fine, and even grain that is usually free of voids or pockets. It's highly stable and extremely durable with a wide variety of finishes available.

Like any product, below are a few extra tips to make sure your mahogany furniture is enjoyable for years to come:

- Be careful of heating sources and air conditioning vents. This can cause the wood to shrink.
- Water marks and stains can occur if not cared for properly. Use a damp cloth and follow up with a dry cloth right away.
- Use coasters to avoid condensation to prevent damage to the surface. If a slight mark is found, you can try lemon oil to remove. Afterwards apply polish for protection.

- Beeswax is recommended but keep in mind the color of your mahogany furniture. You may try a colored cream wax to also prevent fading which at times is easier to apply than a hard wax.
- Be mindful of off-the-shelf abrasive cleaners to avoid discoloration.

## Product Recommendations.

If mahogany gets very sticky (i.e. from a spill), you can use a mild, soapy solution to the damp cloth. We strongly suggest a bleach-free cleaners (without applying directly to the furniture) and don't use very hot water. You must ensure that you wipe with a clean, damp cloth to remove traces of detergent, and follow up with a soft, dry cloth immediately after.

Below is a mild cleaner to clean most mahogany surfaces.





**Walters™**

[walterswicker.com/materials](http://walterswicker.com/materials)